

OhO Sunshine Audio Glasses User Guide

Thank you for choosing **OHO SUNSHINE** Smart Glasses.
Please read this user guide carefully before use.



Scan to learn more

Learn more about our glasses styles and brand information.



ohosunshine.com



PRODUCT PREVIEW

Diagram illustrating the components of the smart glasses:

- 1 Left Speaker
- 2 Microphone
- 3 LED Light
- 4 Right Speaker
- 5 Command Button
- 6 USB Port
- 7 Power on / off Button

⚡ Charging the battery

Diagram illustrating the charging process:

The glasses are shown with a red charging cable connected to the USB port (6) on the side of the frame.

For the best experience with your new glasses, fully charge the battery before first use.



For the best experience with your new glasses, fully charge the battery before first use.

④ Operation




Power On / Off

- Press the **power on/off** button once to answer an incoming phone call.
- Press the **power on/off** button twice to decline an incoming phone call.
- Press the **power on/off** button once to hang up a call.
- Double-click the **power on/off** button to access Siri or other voice assistant.



Command Button

- While music is playing, double-click the **Command Button** to switch songs.
- Keep pressing the **Command Button** to increase the volume.




- While music is playing, double-click the **Command Button** to switch songs.
- Keep pressing the **Command Button** to increase the volume.

● **Pairing to smart devices**

The diagram shows a pair of glasses with a rectangular module on the right temple. A red arrow points from the text "LED" to a small circular indicator on this module. The glasses are shown in a side profile view.

To pair your glasses with a smart device, press the power on/off button. When the blue and red LED lights flash alternately, activate Bluetooth on your device and select **"OhO sunshine"** to connect.



To pair your glasses with a smart device, press the power on/off button. When the blue and red LED lights flash alternately, activate Bluetooth on your device and select **"OhO sunshine"** to connect.

⚠ Warnings and Important Information

- If you do not use the glasses for an extended period, please fully charge them before use.
- The recommended operating temperature is between 32°F and 104°F.
- These spectacles are designed for use in humid environments, splashing water, or rainy conditions. Do not submerge the glasses in water.
- Avoid using the glasses in environments with high dust density to prevent contamination of components.
- The glasses are not suitable for driving in twilight, at night, or in poor light conditions.

- If you do not use the glasses for an extended period, please fully charge them before use.
- The recommended operating temperature is between 32°F and 104°F.
- These spectacles are designed for use in humid environments, splashing water, or rainy conditions. Do not submerge the glasses in water.
- Avoid using the glasses in environments with high dust density to prevent contamination of components.
- The glasses are not suitable for driving in twilight, at night, or in poor light conditions.

Made in China, ETL to EN301

Made in China. Elite en301